

# Digital Photography

## Tips, Techniques and Pointers



### INTRAORAL:

- w/ flash (macro light or ringlight) ISO 200 or 400
- Exposure mode manual
- Shutter speed 1/60 sec.
- Aperture f 11 or f 16
- Frame as tightly as possible
- If photographing the whole arch, focus approximately at the pre-molars

### EXTRAORAL or FACIAL:

- w/ flash ISO 200 or 400
- Exposure mode manual
- Shutter speed 1/60 sec.
- Aperture f 5.6 or 8
- For full face focus on the eyes

### FLASH TIPS:

- A flash can only expose properly for one distance-expose for the point of emphasis. Your camera may over or underexpose in these situations-use flash exposure compensation
- If the photo is too light, use minus
- If the photo is too dark, use plus

All your photos can be emailed to:

[Sundancedl@aol.com](mailto:Sundancedl@aol.com)



8010 E. McDowell Rd. Ste 223  
Scottsdale AZ. 85257  
Phone: 480-429-3543  
Fax: 480-429-3697

Email: [Sundancedentallab.com](http://Sundancedentallab.com)